


5A-0514-2 BACK-GOUGING MINI SAW

EXPLODED VIEW



PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
1	001011102	Housing (1/4"-18 NPT)	1	29	0D03	Oil Drop	1		5A-0514-2-RK	Repair Kit	1
	001011102-2	Housing (1/4"-19 PT)	1	30	073021080	Angle Housing	1			(parts available in kit only)	
2	030021080	Trigger	1	32	035031080	Lock nut	1	9		Ball Bearing 606zz	1
3	SP3022	Spring Pin	1	34	025011104	Anvil	1	13		Blade	4
4	010011018	Pin Valve Rod	1	36	017021080	Cylinder Set Screw	1	17		Ball Bearing 608zz	1
8	049011101	Screw	1	37	018011104	Bushing	1	19		O-Ring	1
10	011011101	Rear Plate	1	39	035051104	Lock nut	1	24		Ball Bearing 6900zz	2
11	SP1506	Spring Pin	2	41	082021104	Wheel Guard	1	26		Ball Bearing BRBA88Z	1
12	012011101	Cylinder	1	42	SC10618	Screw	1	27		Driving Gear Spindle	1
14	013011101	Rotor	1	47	W014P	Wrench	1	31		Ball Bearing 695zz	1
15	015011101	Front Plate	1	48	W013P	Wrench	1	33		Bevel Gear	1
16	016021027	Washer	1					35		Key	1
18	017011102	Cylinder Set Screw	1		5A-0514-2-TK	Tune Up Kit	1				
20	004011102	Exhaust Deflector	1			(parts available in kit only)			ACCESSORIES		
21	027011104	Front Casing	1	5		Packing	1	34	025011104	Anvil	1
22	040011104	Bushing	1	6		Spring	1	43	082031104	Wheel Guard	1
23	017031080	Cylinder Set Screw	1	7		O-Ring	1	37	018011104	Bushing	1
25	018021080	Bushing	1	59		Air Strainer	1	46	035031104	Lock nut	1
28	017011104	Cylinder Set Screw	1								

FOOTNOTES

EAGLE
GROUP
A Division of AIMCO

10000 SE PINE
PORTLAND, OR 97216
503-254-6600
FAX 503-255-2615

When ordering spare parts, please specify
tool type, part number, and description

REVISED 05/19